



# MMC and SD Media Driver for SPI User Guide

Version 1.70

For use with MMC and SD Media Driver for SPI versions 2.02 and above

Exported on 09/24/2018

All rights reserved. This document and the associated software are the sole property of HCC Embedded. Reproduction or duplication by any means of any portion of this document without the prior written consent of HCC Embedded is expressly forbidden.

HCC Embedded reserves the right to make changes to this document and to the related software at any time and without notice. The information in this document has been carefully checked for its accuracy; however, HCC Embedded makes no warranty relating to the correctness of this document.

## Table of Contents

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>System Overview.....</b>                    | <b>3</b>  |
| 1.1      | Introduction .....                             | 4         |
| 1.2      | Feature Check .....                            | 5         |
| 1.3      | Packages and Documents .....                   | 6         |
|          | Packages.....                                  | 6         |
|          | Documents .....                                | 6         |
| 1.4      | Change History .....                           | 7         |
| <b>2</b> | <b>Source File List .....</b>                  | <b>8</b>  |
| 2.1      | API Header File .....                          | 8         |
| 2.2      | Configuration Files.....                       | 8         |
| 2.3      | System File .....                              | 8         |
| 2.4      | Version File .....                             | 8         |
| 2.5      | Platform Support Package (PSP) Files.....      | 9         |
| <b>3</b> | <b>Configuration Options .....</b>             | <b>10</b> |
| 3.1      | config_mdriver_mmcsd_spi.h .....               | 10        |
| 3.2      | config_mdriver_mmcsd_spi.c.....                | 11        |
| <b>4</b> | <b>Application Programming Interface .....</b> | <b>12</b> |
| 4.1      | mmcsd_spi_initfunc .....                       | 13        |
| 4.2      | mmcsd_spi_get_cid.....                         | 14        |
| 4.3      | F_DRIVER Structure .....                       | 15        |
| 4.4      | CID Register .....                             | 16        |
| 4.5      | Error Codes.....                               | 17        |
| <b>5</b> | <b>Integration.....</b>                        | <b>18</b> |
| 5.1      | PSP Porting .....                              | 18        |
|          | mmcsd_hw_init .....                            | 20        |
|          | mmcsd_hw_delete .....                          | 21        |
|          | mmcsd_hw_card_is_present.....                  | 22        |
|          | mmcsd_hw_card_is_wp.....                       | 23        |

# 1 System Overview

This chapter contains the fundamental information for this module.

The component sections are as follows:

- [Introduction](#) – describes the main elements of the module.
- [Feature Check](#) – summarizes the main features of the module as bullet points.
- [Packages and Documents](#) – the *Packages* section lists the packages that you need in order to use this module. The *Documents* section lists the relevant user guides.
- [Change History](#) – lists the earlier versions of this manual, giving the software version that each manual describes.

**Note:** To download this manual as a PDF, see [File System Media Driver PDFs](#).

## 1.1 Introduction


This guide is for those who want to use HCC Embedded's MMC and SD Media Driver for SPI in their system. This module provides a media driver for HCC's `psp_spi` interface, which can be provided for any standard microcontroller. You simply need to port `psp_spi` to your target and the driver calls your functions. This guide covers all aspects of configuration and use.

**Note:** HCC provides tested SPI drivers for most standard microcontrollers that conform to HCC's [PSP SPI specification](#).

This media driver conforms to the [HCC Media Driver Interface Specification](#).

The media driver provides an interface for a file system to read from and write to Secure Digital (SD) or MultiMediaCard (MMC) storage devices. A single media driver can support one or more physical media, each of these being represented as a different drive at the media driver interface. The file system handles all drives identically, regardless of their internal design features.

The diagram below shows a typical system architecture including a file system, media driver and media. As an example, this shows one MMC and one SD card.



## 1.2 Feature Check

The main features of the media driver are the following:

- Conforms to the HCC Advanced Embedded Framework.
- Designed for integration with both RTOS and non-RTOS based systems.
- Conforms to the *HCC Media Driver Interface Specification*.
- Supports multiple MMC/SD devices.
- Supports multiple card types: MMC/SD and also SDHC (Secure Digital High Capacity) and SDXC (Secure Digital eXtended Capacity).
- Supports eMMC (embedded MMC).

## 1.3 Packages and Documents

### Packages

The table below lists the packages that you need in order to use this module:

| Package                    | Description  |
|----------------------------|--|
| <b>hcc_base_doc</b>        | This contains the two guides that will help you get started.             |
| <b>media_drv_base</b>      | The base media driver that includes the framework all media drivers use. |
| <b>media_drv_mmcsd_spi</b> | The media driver package described in this document.                     |
| <b>psp_template_spi</b>    | The SPI Platform Support Package (PSP).                                  |
| <b>oal_base</b>            | The base OS Abstraction Layer (OAL) package, needed if an RTOS is used.  |

### Documents

For an overview of HCC file systems and data storage, see [Product Information](#) on the main HCC website.

Readers should note the points in the [HCC Documentation Guidelines](#) on the HCC documentation website.

#### **HCC Firmware Quick Start Guide**

This document describes how to install packages provided by HCC in the target development environment. Also follow the *Quick Start Guide* when HCC provides package updates.

#### **HCC Source Tree Guide**

This document describes the HCC source tree. It gives an overview of the system to make clear the logic behind its organization.

#### **HCC Media Driver Interface Guide**

This document describes the HCC Media Driver Interface Specification.

#### **HCC MMC and SD Media Driver for SPI User Guide**

This is this document.

## 1.4 Change History

This section describes past changes to this manual.

- To download this manual or a PDF describing an [earlier software version](#), see [File System Media Driver PDFs](#).
- For the history of changes made to the package code itself, see [History: media\\_drv\\_mmcsd\\_spi](#).

The current version of this manual is 1.70. The full list of versions is as follows:

| Manual version | Date       | Software version | Reason for change   |
|----------------|------------|------------------|---|
| 1.70           | 2018-09-24 | 2.02             | Added second note on PSP Files in <i>Source Files</i> section.  |
| 1.60           | 2018-03-22 | 2.02             | Added SPI_MAX_BAUDRATE configuration option.  |
| 1.50           | 2018-03-09 | 2.01             | Added <b>oal_base</b> to <i>Packages</i> list.<br>Functions "mmcsd_xxxx" renamed to "mmcsd_spi_xxxx".<br>Error messages renamed "MMCSD_SPI_xxxxx".<br>Added configuration option ENABLE_HIGH_SPEED. |
| 1.40           | 2017-06-23 | 1.19             | New <i>Change History</i> format.   |
| 1.30           | 2015-11-23 | 1.18             | Added note to <i>Introduction</i> .   |
| 1.20           | 2015-08-24 | 1.18             | Various small changes.  |
| 1.10           | 2015-05-08 | 1.15             | Added <i>Change History</i> .   |
| 1.00           | 2015-03-20 | 1.15             | First online version.   |

## 2 Source File List

This section describes all the source code files included in the system. These files follow the HCC Embedded standard source tree system, described in the [HCC Source Tree Guide](#). All references to file pathnames refer to locations within this standard source tree, not within the package you initially receive.

**Note:** Do not modify any files except the configuration files and PSP files.

### 2.1 API Header File

The file `src/api/api_md�iver_mmcsd_spi.h` is the only file that should be included by an application using this module. For details of the API functions, see [Application Programming Interface](#).

### 2.2 Configuration Files

The following files in the directory `src/config` contain all the configurable parameters of the system. Configure these as required. For details of these options, see [Configuration Options](#).

| File                                    | Description                |
|---|----------------------------|
| <code>config_md�iver_mmcsd_spi.h</code> | Configuration options.     |
| <code>config_md�iver_mmcsd_spi.c</code> | SPI unit ID configuration. |

### 2.3 System File

The file `src/media-drv/mmc-spi/mmcsd_spi.c` is the source code for the media driver. **This file should only be modified by HCC.**

### 2.4 Version File

The file `src/version/ver_md�iver_mmcsd_spi.h` contains the version number of this module. This version number is checked by all modules that use this module to ensure system consistency over upgrades.



## 2.5 Platform Support Package (PSP) Files

These files provide functions the core code needs to call, depending on the hardware. They are in the directory `src/psp/target/mmc-spi`.

**Note:**

- You must modify these PSP implementations for your specific microcontroller and development board; see [PSP Porting](#) for details.
- In the package these files are offset to avoid overwriting an existing implementation. Copy them to the root **hcc** directory for use.

| File                      | Description           |
|---------------------------|-----------------------|
| <code>mmc-spi_hw.c</code> | Source code.          |
| <code>mmc-spi_hw.h</code> | Function definitions. |

## 3 Configuration Options

System configuration is controlled by two files in **src/config**.

### 3.1 config\_mdriver\_mmcsd\_spi.h

Set the system configuration options in this file. This section lists the available configuration options and their default values.

#### **USE\_CRC**

Keep the default of 1 to use CRC for communication. Otherwise, set this to 0.

#### **CRC\_ROM\_TABLE**

Keep the default of 1 to put the CRC table in ROM. Otherwise, set this to 0.

#### **RTOS\_SUPPORT**

Keep the default of 1 if the driver is used with an RTOS. This is only required to perform wait cycles with *osal\_task\_sleep* instead of SPI transactions.

#### **MAX\_UNITS**

The maximum number of MMC/SD units supported. The default is 1.

#### **OVERRIDE\_SDHC\_TIMEOUTS**

Set this to 1 for any card that does not meet SDHC standards, for example a Swissbit® card. The default is 0.

#### **VALID\_VOLTAGE\_RANGE**

The valid voltage range. The default of 0x00FF8000 means 2.7 - 3.6 V.

#### **ENABLE\_HIGH\_SPEED**

Keep the default of 1 to enable switching to High Speed mode for cards that support this mode. Otherwise, set this to 0.

#### **SPI\_MAX\_BAUDRATE**

The maximum SPI clock speed in [Hz]; set this as required. The default of 0 means there is no limit.

## 3.2 config\_mdriber\_mmcsd\_spi.c

This file sets the SPI unit ID configuration. This is defined by default as follows:

```
const uint8_t g_mmcsd_spi_uid[MAX_UNITS] =  
{  
    0  
};
```

## 4 Application Programming Interface

This section describes the functions, the structure and typedef they use, and the error codes.

When the media driver is used:

1. The file system calls the media driver's **mmcsd\_spi\_initfunc()** function.
2. **mmcsd\_spi\_initfunc()** returns a pointer to an F\_DRIVER structure containing a set of functions for accessing the media driver.

## 4.1 mmcsd\_spi\_initfunc

Use this function to initialize the interface with the driver.

The caller passes a parameter to the initialization function of a conforming driver. The driver returns a pointer to an `F_DRIVER` structure defining the interface to that driver.

**Note:** The call must allocate or use a static structure for the `F_DRIVER` structure. It must return a pointer to this structure, which must contain all the driver entry points, and also other data as required.

### Format

```
F_DRIVER * ( mmcsd_spi_initfunc )( unsigned long driver_param )
```

### Arguments

| Argument     | Description  | Type          |
|--------------|--|---------------|
| driver_param | This identifies the drive to use. The first drive is 0. This cannot be greater than (MDRIVER_MAX_VOLUME - 1) | unsigned long |

### Return values

| Return value | Description   |
|--------------|---|
| F_DRIVER *   | A pointer to the driver structure, or NULL if the request failed. |

## 4.2 mmcsd\_spi\_get\_cid

Use this function to get the content of the Card ID (CID) register.

**Note:** You must call `mmcsd_spi_initfunc()` before this function.

### Format

```
int mmcsd_spi_get_cid (  
    unsigned long    driver_param,  
    t_mmcsd_cid *    p_cid )
```

### Arguments

| Argument     | Description   | Type          |
|--------------|---|---------------|
| driver_param | This identifies the drive to use. The first drive is 0. | unsigned long |
| p_cid        | A pointer to the CID buffer.                            | t_mmcsd_cid * |

### Return values

| Return value                 | Description                   |
|------------------------------|-------------------------------|
| MMCSD_SPI_NO_ERROR           | Successful execution.         |
| MMCSD_SPI_ERR_NOTINITIALIZED | The drive is not initialized. |

## 4.3 F\_DRIVER Structure

This is the format of the *F\_DRIVER* structure. This structure is defined in the [HCC Media Driver Interface Specification](#).

| Element             | Type                  | Description   |
|---------------------|-----------------------|---|
| separated           | int                   | Non-zero if the driver is separated.  |
| user_data           | unsigned long         | User-defined data.  |
| user_ptr            | void *                | User-defined pointer.   |
| writesector         | F_WRITESECTOR         | Write a sector to the drive. This is mandatory if format or any write access is required. |
| writemultiplesector | F_WRITEMULTIPLESECTOR | Write a series of sectors to the drive. If this is unavailable F_WRITESECTOR may be used. |
| readsector          | F_READSECTOR          | Read a sector from the drive.   |
| readmultiplesector  | F_READMULTIPLESECTOR  | Read a series of sectors from the drive. If this is unavailable F_READSECTOR may be used. |
| getphy              | F_GETPHY              | Used to get the physical properties of the drive, such as the number of sectors.          |
| getstatus           | F_GETSTATUS           | (Only for removable drives) Used to test whether a drive has been removed or changed.     |
| release             | F_RELEASE             | Release any resources associated with a drive when it is freed by the host (file) system. |
| ioctl               | F_IOCTL               | Used to send user-defined messages to the driver and get a response.                      |

## 4.4 CID Register

This is the format of the `t_mmcsd_cid` typedef:

| Element       | Type     | Description   |
|---------------|----------|---|
| manuf_id      | uint8_t  | MID – Manufacturer ID (3=SanDisk, 2=Kingston, and so on).     |
| oem_id[3]     | char_t   | OID – OEM/Application ID (ASCII characters on SD, ID on MMC). |
| product_name  | char_t   | PNM – Product name (ASCII, 5 or 6 characters).                |
| version_major | uint8_t  | PRV – Product revision, major.                                |
| version_minor | uint8_t  | PRV – Product revision, minor.                                |
| serial_number | uint32_t | PSN – Product serial number.                                  |
| manuf_year    | uint16_t | MDT – Manufacturing year (decoded from MDT).                  |
| manuf_month   | uint8_t  | MDT – Manufacturing month (decoded from MDT).                 |



## 4.5 Error Codes

If a function executes successfully, it returns with `MMCSPI_NO_ERROR`, a value of zero. The following table shows the meaning of the error codes.

| Return Value                           | Value | Description               |
|--|-------|---------------------------|
| <code>MMCSPI_ERR_NOTPLUGGED</code>     | -1    | For high level.           |
| <code>MMCSPI_NO_ERROR</code>           | 0     | Successful execution.     |
| <code>MMCSPI_ERR_NOTINITIALIZED</code> | 0x65  | Driver not initialized.   |
| <code>MMCSPI_ERR_INIT</code>           | 0x66  | Initialization error.     |
| <code>MMCSPI_ERR_CMD</code>            | 0x67  | Command error.            |
| <code>MMCSPI_ERR_STARTBIT</code>       | 0x68  | Start bit error.          |
| <code>MMCSPI_ERR_BUSY</code>           | 0x69  | Driver already active.    |
| <code>MMCSPI_ERR_CRC</code>            | 0x70  | CRC error.                |
| <code>MMCSPI_ERR_WRITE</code>          | 0x71  | Write error.              |
| <code>MMCSPI_ERR_WRITEPROTECT</code>   | 0x72  | Media is write-protected. |
| <code>MMCSPI_ERR_NOTAVAILABLE</code>   | 0x73  | Media not available.      |

## 5 Integration

This section describes all aspects of the module that require integration with your target project. This includes porting and configuration of external resources.

### 5.1 PSP Porting

The Platform Support Package (PSP) is designed to hold all platform-specific functionality, either because it relies on specific features of a target system, or because this provides the most efficient or flexible solution for the developer.

The module makes use of the following standard PSP functions:

| Function            | Package  | Component  | Description  |
|---------------------|----------|------------|--|
| <b>psp_memcpy()</b> | psp_base | psp_string | Copies a block of memory. The result is a binary copy of the data. |
| <b>psp_memset()</b> | psp_base | psp_string | Sets the specified area of memory to the defined value.            |

The module makes use of the following standard PSP SPI functions. For details of these functions, refer to the [HCC SPI Driver PSP User Guide](#).

| Function                      | Package  | Component | Description   |
|-------------------------------|----------|-----------|---|
| <b>psp_spi_init()</b>         | psp_base | psp_spi   | Initializes the SPI port.   |
| <b>psp_spi_start()</b>        | psp_base | psp_spi   | Starts the SPI port.  |
| <b>psp_spi_cs_hi()</b>        | psp_base | psp_spi   | Sets chip select high.  |
| <b>psp_spi_cs_lo()</b>        | psp_base | psp_spi   | Sets chip select low.   |
| <b>psp_spi_get_baudrate()</b> | psp_base | psp_spi   | Gets the baudrate.  |
| <b>psp_spi_set_baudrate()</b> | psp_base | psp_spi   | Sets the baudrate.  |
| <b>psp_spi_rx()</b>           | psp_base | psp_spi   | Receives a number of bytes.   |
| <b>psp_spi_tx()</b>           | psp_base | psp_spi   | Transmits a number of bytes.  |
| <b>psp_spi_tx1()</b>          | psp_base | psp_spi   | Transmits one byte.   |
| <b>psp_spi_lock()</b>         | psp_base | psp_spi   | Locks the SPI for the specific unit. This can be useful if multiple units are attached to the same SPI bus. |

| Function                | Package  | Component | Description   |
|-------------------------|----------|-----------|---|
| <b>psp_spi_unlock()</b> | psp_base | psp_spi   | Unlocks the SPI for the specific unit. This can be useful if multiple units are attached to the same SPI bus. |

The module makes use of the following PSP functions. These functions are provided by the PSP to perform various tasks. Their design makes it easy for you to port them to work with your hardware solution. The package includes samples in the PSP file **src/psp/target/mmcsd-spi/mmcsd-spi\_hw.c**.

| Function                          | Description   |
|-----------------------------------|---|
| <b>mmcsd_hw_init()</b>            | Initializes the hardware.                             |
| <b>mmcsd_hw_delete()</b>          | Deletes the device, releasing associated resources.   |
| <b>mmcsd_hw_card_is_present()</b> | Checks whether a card is present.                     |
| <b>mmcsd_hw_card_is_wp()</b>      | Checks whether the card's write-protect switch is on. |

These functions are described in the following sections.

## mmcscd\_hw\_init

This function is provided by the PSP to initialize the device.

### Format

```
int mmcscd_hw_init ( uint8_t uid )
```

### Arguments

| Argument | Description  | Type    |
|----------|--------------|---------|
| uid      | The unit ID. | uint8_t |

### Return Values

| Return value      | Description           |
|-------------------|-----------------------|
| MMCS_D_HW_SUCCESS | Successful execution. |
| MMCS_D_HW_ERROR   | Operation failed.     |

## mmcsd\_hw\_delete

This function is provided by the PSP to delete the device, releasing the associated resources.

### Format

```
int mmcsd_hw_delete( uint8_t uid )
```

### Arguments

| Argument | Description  | Type    |
|----------|--------------|---------|
| uid      | The unit ID. | uint8_t |

### Return Values

| Return value     | Description           |
|------------------|-----------------------|
| MMCSD_HW_SUCCESS | Successful execution. |
| MMCSD_HW_ERROR   | Operation failed.     |

## mmcsd\_hw\_card\_is\_present

This function is provided by the PSP to report whether a card is inserted.

### Format

```
int mmcsd_hw_card_is_present ( uint8_t uid )
```

### Arguments

| Argument | Description  | Type    |
|----------|--------------|---------|
| uid      | The unit ID. | uint8_t |

### Return Values

| Return value | Description         |
|--------------|---------------------|
| 0            | No card is present. |
| 1            | A card is present.  |

## mmc\_sd\_hw\_card\_is\_wp

This function is provided by the PSP to get the Write Protect state of the card.

### Format

```
int mmc_sd_hw_card_is_wp ( uint8_t uid )
```

### Arguments

| Argument | Description  | Type    |
|----------|--------------|---------|
| uid      | The unit ID. | uint8_t |

### Return Values

| Return value | Description                  |
|--------------|------------------------------|
| 0            | The card is not protected.   |
| 1            | The card is write-protected. |